






Sammode
Éclairage technique depuis 1927

GRID LAMPS 180°

Notice de montage


Mounting instruction

Montageanleitung




L	Ø	Entraxe max	Poids
(mm)	(mm)	(mm)	(kg)
519	100	470	1,6
1295	133	1230	5


Installation & raccordement / Wiring / Verkabelung





1.




2.




3.




4.




5.



6.




7.









Maintenance


Maintenance / Wartung



Ne pas ouvrir sous tension
Do not open when energized
Nicht unter Spannung öffnen





1. Position & câble / Position & cable / Position & Kabel



2. Flasques / End caps / Endkappen

3. Vis centrale / Central screw / Zentrale Schraube



Sammode SA

24 rue des Amandiers, F-75020 Paris

Notice GRID LAMPS 180°

Juin 2023